

10 cm

X6

10 cm

X3

X3



X1




9X

9X

X6


X3







rails for X6
laminated to 0,5 mm



rails for A9
laminated to 0,5 mm




assembling of part X (x 2)



base for long bogie




base for locomotive




short bogie


Before assembling make **ring mark** on the centre of the rod (9 mm from any end) then glue sw3 superposing its **green line** with this mark. Parts sw2 laminate to 1,6 mm.



sw4 - wood rod 2 mm 18 mm length




10 cm








long bogie

Before assembling make **ring mark** on the centre of the rod (13 mm from any end) then glue flw3 superposing its **green line** with this mark. Parts flw2 laminate to 1,6 mm.











Before assembling make **ring mark** on the centre of the rod (9 mm from any end) then glue rlw3 superposing its **green line** with this mark. Parts rlw2 laminate to 1,6 mm.




remotely-operated electric locomotive

10 cm









wheel pair for locomotive



Before assembling make **ring mark** on the centre of the rod (13 mm from any end) then glue dw3 superposing its **green line** with this mark. Parts dw2 laminate to 1,6 mm.



car trucks



10 cm